

Requirement for final value of archive function

The function that is executed over the values from an archive block must be defined through the Declaration part – **FUNCTION**. The following [DDE reference](#) is used to get the value of the function:

= D_2000 | FUNC_VALUE ! blname

D_2000 - DDE Server name (required).

FUNC_VALUE - requirement for the value of defined function.

blname - logical name of archive block (COM_ID).

The example of DDE reference is - [here](#).



Related pages:

[Archive values](#)

[The functions working with archive values](#)

[Requirement for particular archive value](#)

[Requirement for status of archive block](#)

[Requirement for number of values in archive block](#)