



Levels in graph

The graph flows may be split into the levels - [axis levels](#) or [object levels](#) (see [object configuration](#)).

The level height may be adjusted as follows:

1. Switch off a control button **Pointer** .
2. Move the cursor on the place between the levels - a split bar appears (1).
3. Click the left mouse button and move the split bar.
4. Release the left mouse button.



Notes

1. The level split according to [axis](#): both a proportional division in the graph and a change of the number of levels (when some of the flows is switch off) are kept.
2. The level split according to [objects](#): the visible flows are evenly split when the number of levels was changed.



Related pages:

[Graphs](#)

[Graph window](#)