

Trunc

%Trunc function

Function

The function trims the decimal part of a real number.

Declaration

```
REAL %Trunc(  
    REAL in number  
)
```

Parameters

number	Function argument.
--------	--------------------

Example

```
REAL _A  
  
_A := %Trunc(15.237123)  
  
; (_A is 15)
```



Related pages:

[Implemented functions](#)

[Function arguments - types](#)