

StructStatMIN

%StructStatMIN function

Function

The function returns the minimum value from valid values of a given structured variable column. Row range is defined by the parameters *first_row* a *last_row*.
The result is a real number.

Declaration

```
REAL %StructStatMIN(  
    in StructVar^Column,  
    INT in first_row,  
    INT in last_row  
)
```

Parameters

StructVar	Structured variable.
Column	Structured variable column.
first_row, last_row	Range of rows in the column.

Example

```
%StructStatMIN(SV.Structure^Int, 4, 6)
```



Related pages:

[Implemented functions](#)
[Function arguments - types](#)