Delete the Picture Content

Deleting the picture content

To delete the picture contents select the item **Clear Picture** from the menu **Edit**. Clicking the item opens the dialog to confirm deleting the picture. Clicking the button **Yes** deletes all the graphic objects included in the picture.

i	Related pages:
	Create a new picture
	Open a picture
	Close the picture
	Save the picture
	Picture parameters
	Resize the picture
	Work with several pictures