

Distance between objects

Distance between graphic objects

The [D2000 GrEditor](#) contains the tools, that allow us to set equal distances between the graphic objects.

- Distance by two first objects in the X-axis direction
- Distance by the first and last object in X-axis direction
- Distance by the first two objects in Y-axis direction
- Distance by the first and last object in Y-axis direction

How to adjust the distances between graphic objects

1. Select the objects between which you want to adjust the equal distance. You may select 3 up to 100.
2. In the [Edit](#) toolbar click the appropriate button for the distance, or select the option **Distances** from the [popup menu](#) which opens after clicking the right mouse button over the object in a picture.



Related pages:

[Editing graphic objects](#)