

Select Alarms in the Alarm List (Work with D2000 HI)

Selecting alarms in the Alarm list

Each alarm is selected from the list by mouse clicking the alarm name. To execute an operation for a selection of alarms you must select these alarms first. You can select a continuous or a discontinuous selection of alarms.

To select a continuous selection of alarms

1. Click the first alarm of the selection.
2. Press and hold down the **Shift** key.
3. Click the last alarm of the selection.

To select a discontinuous selection of alarms

1. Press and hold down the **Ctrl** key.
2. Click the alarm names you want to add to the selection.

Note

- To select all alarms in the list press the CTRL+A shortcut.