

GetDragDataIPS

%SetDragDataIPS, %GetDragDataIPS functions

Functions	Function %SetDragDataIPS sets a data container as a source of data for Drag&Drop. Function %GetDragDataIPS returns a data container, which is just transferred during Drag&Drop. If the function %IsDragData(0, _CF_IPS) does not return @TRUE, the return value of this function is undefined.				
Declaration	<pre>%SetDragDataIPS(INT in refId, INT in cntData) INT %GetDragDataIPS(INT in refId)</pre>				
Parameters	<table><tr><td>refId</td><td>It always requires 0.</td></tr><tr><td>cntData</td><td>Data container.</td></tr></table>	refId	It always requires 0.	cntData	Data container.
refId	It always requires 0.				
cntData	Data container.				
Return value	INT - returns a data container which is moved during Drag&Drop.				



Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)