

LnPerf_IncRetryErr

Declaration

```
void (_stdcall *LnPerf_IncRetryErr)(HOBJ LnID)
```

Parameters

LnID	Line ID .
------	---------------------------

Description

The function increments the number of errors of operation retry on the given [Line](#).



Related pages:

[D2000 KomAPI - call-back functions](#)