

# StPerf\_IncFramesOut

## Declaration

```
void (_stdcall *StPerf_IncFramesOut)(HOBJ StID)
```

## Parameters

StID	<a href="#">Station ID</a> .
------	------------------------------

## Description

The function increments the number of frames that were sent from the given [Station](#).



### Related pages:

[D2000 KomAPI - call-back function](#)