

GetFastPoint

Declaration

```
void (_stdcall *GetFastPoint)(HOBJ StId, unsigned int *FastAdr,  
    PointParPtr *PtParPtr);
```

Parameters

StID	ID of the I/O tag parent - station .
FastAdr	Numerical form of I/O tag address.
PtParPtr	Pointer to the PointPar structure. If the value of the pointer is NULL, the defined I/O was not found.

Description

According to the parameter *FastAdr* - numerical address form, the function finds the I/O tag of defined station and returns the pointer to a [PointPar](#) structure of the I/O tag if it exists. Otherwise, the NULL value is returned. For more information see - [addresses of stations and I/O tags](#).



Related pages:

[D2000 KomAPI - call-back functions](#)