

PointsApplyBack

Declaration

```
void _stdcall PointsApplyBack(struct PointPar * Pt, void * AplPar)
```

Parameters

Pt	Pointer to PointPar structure.
AplPar	Void pointer (it is defined as one of the parameters of the function PointsApply).

Description

The function **PoitsApplyBack** (`_PointsApplyBack@8` in the *Stdcall* call convention) is optional. It is a response to the calling of the call-back function [PointsApply](#). The function is called specially for all I/O tags of the station defined in the parameter *Std* of the call-back function [PointsApply](#).



Related pages:

[D2000 KomAPI - interface functions](#)