

PointsApply

Declaration

```
void (_stdcall * PointsApply)(H0BJ StID, void * AplPar);
```

Parameters

StID	Station ID. A series of function PointsApplyBack calls will be generated for all I/O tags of the station.
Adr	I/O tag address (Adr1).
AplPar	Pointer that is transmitted to the calling of the function PointsApplyBack .

Description

After calling the function **PointsApply**, the [D2000 KOM](#) process calls the interface function [PointsApplyBack](#) for all I/O tags of defined station with called ID and gives the parameter *AplPar*. The function mostly eliminates a necessity to keep own lists of I/O tags.



Related pages:

[D2000 KomAPI - call-back functions](#)