

First Login to D2000 System

First login to D2000 system

For the first login to D2000 system, use the following default name and password:

name: **SystemD2000**

password: **SystemD2000**

Note:

Use the name and password to run for the first time [D2000 CNF](#) process, which is used to define users and their access rights. After successful login to one of processes, it is strongly recommended to delete (or change) the user (name and password) to avoid any unauthorized use.



Related pages:

[Users and access rights in D2000 system](#)