

HI_SetEmptyIntervalsVisible

%HI_SetEmptyIntervalsVisible, %HI_GetEmptyIntervalsVisible functions

Function

The function **%HI_SetEmptyIntervalsVisible** sets to leave out an interval without data for the graphic flows in a [Graph](#) displayer.

The function **%HI_GetEmptyIntervalsVisible** returns the setting in a [Graph](#) displayer.

Declaration

```
%HI_SetEmptyIntervalsVisible(  
    INT in refId,  
    BOOL in bVisible  
)  
  
BOOL %HI_GetEmptyIntervalsVisible(  
    INT in refId  
)
```

Parameters

refId	Reference to a displayer (reference variable).
bVisible	TRUE - enables to leave out the intervals without data. FALSE - disables to leave out the intervals without data.



Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)
- [%HI_SetEmptyIntervalDuration](#)