

NtV

%NtV function

Function

Function sets the defined occurrence time for the given expression value. Result is a value of the same type as the expression.

Declaration

```
UNIVAL  %NtV(  
        in Expression,  
        TIME in Time  
    )
```

Parameters

Expression	Optional expression.
Time	Value of Absolute time type, that determines the time of the value of the expression <i>Expression</i> .

Example

```
%NtV(P.SpeedFilterSim_PB+5, U.UVAR_TA\TIM)
```



Related pages:

[Implemented functions](#)

[Function arguments - types](#)