

ERR_NR_TRANS_EX - List of existing errors

The following table contains the list of existing errors returned by the local variable ERR_NR_TRANS_EX.

Internal name	Value	Description
Error codes during work with system objects		
OK	0	OK.
OBJECT_ALREADY_EXISTS	1	The object already exists.
OBJECT_NOT_FOUND	2	The object does not exist.
INVALID_ACCESS	3	Insufficient access rights.
SHARED_ACCESS_ERROR	4	Access error when trying to edit (object is being edited by other users).
OBJECT_NOT_OPENED	5	The object is not open.
OBJECT_IS_USED	6	The object is used (when trying to delete it).
INVALID_NAME	7	Invalid object name.
FATAL_ERROR	8	Fatal error.
OBJECT_IS_READ_ONLY	9	The object is read-only (when trying to edit or delete it).
OBJECT_HAS_CHILDREN	10	The object has children (when trying to delete it).
SAVE_REFERENCES_ERROR	11	Incorrect object references.
LICENCE_LIMIT_OVERFLOW	46	License limit overrun (when trying to create a new object).
Error codes for an output control		
MANUAL_CTRL_DISABLED	12	Manual control disabled (when trying to set a value manually).
BAD_COMMAND	13	Bad command.
COMMAND_NOT_ACCEPTED	14	Illegal command.
PROCESS_NOT_RUNNING	15	The process for the command execution is not running.
Error codes for configuration of the topology		
CREATE_NEW_ERROR	16	Error during the creation of a new object of Topology type.
BAD_PARENT	17	The object has another parent.
NAME_ALREADY_EXISTS	18	Object with the given name already exists - it is of another type.
BAD_CONNECT	19	Inappropriate control object for the topological node of Terminal type.
Error codes for the user's logins		
USER_INVALID_ACCESS	20	Invalid access rights.
LOGON_WRONG_PASSWORD	21	Incorrect password. (version <= 12.2.65)
LOGON_NAME_ERROR	22	Incorrect login name. (version <= 12.2.65)

PASSWORD_EXPIR_TIME	23	Password validity has expired.
USER_IS_DISABLED	24	User login is disabled.
USER_EXPIR_TIME	25	The validity of the user's account has expired.
LOGON_NAME_PASSWORD_ERROR	54	Incorrect name or password. (version >= 12.2.67)
Error codes for a database backup		
DATABASE_NOT_VALID	26	Database not valid.
BACKUP_FAILED	27	Backup failed.
OTHER_ERROR	28	Other error.
PATH_NOT_COMPLETE	29	Path not complete.
Error codes for access to the database (D2000 Archiv, D2000 DBManager, D2000 Server)		
ODBC_ERROR	34	ODBC error.
Error codes for connection to a processes		
INVALID_VERSION	30	Incorrect version.
PROCESS_RUN_DISABLED	31	Cannot start the process.
PROCESS_LICENCE_DISABLED	32	Cannot start the process - insufficient license.
PROCESS_TCPIP_DENIED	33	Cannot start the process - IP address is denied.
Error codes of the D2000 DBManager process		
PAGE_ERROR	35	Page error (in case of page access to the database).
EDIT_DISABLED	36	Editing disabled (when trying to write to a read-only table).
DBM_SEQUENCE_ERROR	37	DBManager sequence error (invalid object identifier, non-existing transaction, ...)
DATABASE_OPEN_ERROR	38	Open database error.
BAD_CONDITION	39	Bad conditions.
TOO_MANY_ROWS_IN_SELECT	48	Too many rows in selection (more than specified by the parameter Maximum returned rows in the configuration of the object of Database type).
DBM_CONNECTION_BROKEN_ERROR	49	Connection with the database has been interrupted.
DBM_MAX_CONNECTIONS	50	The maximum number of connections to the database has been reached (the parameter Maximum connections in the configuration of the object of Database type), a new connection has not been created.
STRUCT_CHANGE	51	Change of object of Structure definition type in runtime (rows loaded from the database do not correspond to the changed object of Structure definition type and are not to be sent to the D2000 Server process).
DBM_DATABASE_OFF	52	Access denied: the object of Database type is set to OFF (the parameter Off in the configuration of the object)
Error codes of the D2000 Archiv process		
LOAD_TREZOR_ERROR	40	Error in loading depository database.
CREATE_WRT_FILE_ERROR	41	Create a WRT file error when importing the Sybase depository database.
OPEN_TREZOR_ERROR	42	Error in opening depository database.
CREATE_STATISTICS_ERROR	43	Error in creating statistics file for the archive.

Error codes of Tell commands for the D2000 KOM process		
DUPLICATE_ADDRESS_ERROR	44	Duplicate address (when changing the address of I/O tag by using the Tell command SETPTADDR)
POINT_NOT_FOUND_ERROR	45	I/O tag not found (for Tell command SETPTADDR).
Error codes of the D2000 Application Manager process		
INVALID_DB_PASSWORD	47	Invalid password for access to the configuration database.

Note: the error codes returned by the **D2000 DBManager** process when calling the `%GetLastExtErrorCode` function are described [here](#).