ExitProcWithLnPar

Declaration

```
void _stdcall ExitProcWithLnPar(LinePar *Ln)
```

Parameters

Ln	Pointer to LinePar.

Description

ExitProc (_ExitProcWithLnPar@4 in Stdcall convention) is called before stopping the D2000 KOM (stopping **D2000 KOM** by a user, stopping D2000 Server). The function handling should be as fast as possible. You should realize that the D2000 KOM process could have been already stopped and the use of call-back function may be incorrect.

Related pages:

D2000 KomAPI - functions