

Basic (HI)

Description of "Graph configuration" dialog box - Parameters

Basic parameters of the graph are being defined in the **Graph configuration** dialog box - **Parameters** tab.

D,Test - (Graph)

D,Test

RevertSave

ParametersObjectsAxesLogic Groups

Description

Color Palette

Graph Type

Timeseries GraphLive DataXY Graph

Timeseries Axis

LengthTime ShiftWithout Spaces

Objects

TogetherY-Axis LevelsObject Levels

☐ Add/Subtract Also Hidden Graph Flows☒ Draw by Archive Period

Y-Axes

☐ Ignore out-of-view Values for Dynamic Y-axis☒ Show Description

Show

☒ Controls Panel☒ Raster☐ Pointer

Help

Export Subdirectory

Table

View on OpenVisible (always)

Visible Rows (max)0

1. columnWeighted Average

2. columnMaximum

3. columnAuto Last Value

4. columnNone

5. columnNone

6. columnNone

☐ Custom Colors

Graph Window:Graph Area:Time Axis:Significant time:

1.1

12:00

Description

A text string describing the content of the graph. Description along with the name will be displayed in the list of graphs. Possibility to use the [Dictionary](#) (to open press **CTRL+L**).

Color palette

Selection of [color palette](#) that will be used for configuration of the given graph.

Graph type

Timeseries graph	
Live Data	The parameter allows automatic drawing the flows of the objects, values of which are being changed in time (live data).
XY Graph	If the option is marked, it is XY graph, otherwise it is the time graph.

Timeseries Axis

Length	Time length determines the range of horizontal time axis (x-axis).
Time shift	The parameter Time shift relates to a time length. It sets a periodic beginning of time axis. If time shifts is e.g. 1 hour then time axis will begin with whole hour. The parameter is enabled, if the parameter Live data is checked.
Without Spaces	A space without data is not drawn (removed from graph). The size is set in a spin box. It relates to every flow which does not contains any data. The removed section starts from a rounded time according to section size and takes up to an integral multiple of the section size. If this value is 0 (zero), this feature is disabled. It can be activated from script when setting the interval on value higher then 1 minute.

Objects

Together	Shows graphs together.
Y - Axis Levels	Displaying graphs on different levels according to the membership to a particular axis. Note: If no graph is bound to an axis, the axis (and the level belonging to it) is not displayed.
Objects Levels	Displaying graphs on different levels according to the membership to an explicitly specified level - which can be set in graph configuration dialog box .
<input type="checkbox"/> Add/Subtract Also Hidden Graph Flows	If the parameter is checked, all additive (subtractive) graphic flows, which are hidden using the button 2 in the graph window, will be added/subtracted into/from the graph.
<input type="checkbox"/> Draw by Archive Period	If checked, the flows of periodical archive data in the graph are to be drawn by the stored time of the data (see the parameter Stored time in the configuration of object of <i>Historical value</i> type).

Y - Axes

Enables/disables the description of Y-axis if is defined (the parameter [Axis description](#) in the [Axis configuration](#) dialog box).

Show


The checkboxes are used to show or hide the particular parts of the graph window after opening. Checked items mean that corresponding parts will be displayed after opening the graph. Descriptive graph table, pointer, grid and common y-axis settings may be enabled/disabled in the graph window by means of corresponding [buttons](#).

Help

The parameter allows to define an [application help](#) page to be opened after pressing the key F1 while the graph is active. If the parameter is not defined, there will be opened the standard D2000 help.

Export subdirectory


Setting the export subdirectory that can be done in two ways:

1. Direct entering to the edit field.
2. Clicking the button , which opens the window to search the required directory with CVS.
Click the **OK** button to confirm your selection. If CVS subdirectory with *Repository file* is not placed in that directory, the user can cancel the action or use the selected path but without the path to **XML Repository folder** at the beginning. This path will occurs in the edit field.

Table

View on Open

The button has three states and enables to configure two ways of hiding the table in connection with the size of graph window.



First way enables to hide / show the table after clicking . It is indicated by grey / yellow color of table icon in the graph. The second one enables to hide the table after the graph window is reduced, which is indicated by dark grey / red color of icon.

The checkboxes are used to show or hide the particular parts of the graph window after opening. Checked items mean that corresponding parts will be displayed after opening the graph. Descriptive graph table, pointer, grid and common y-axis settings may be enabled / disabled in the graph window by means of corresponding [buttons](#).

Max. lines in table

Maximum lines that are displayed in the table below graph. If there are defined more flows in the graph, they will be available through the scrollbar.

The parameters allow to define the contents at most 6 columns of the [graph table](#). There are the following options:

- *Minimum* - minimum object value within the time interval defined for the graph
- *Auto Minimum* - minimum object value within the time interval defined for the graph - the column is visible only when graph displays the non-live data (the parameter [Live data](#) is not checked or when user sets the past by button  **New time interval**)
- *Maximum* - maximum object value within the time interval defined for the graph
- *Auto Maximum* - maximum object value within the time interval defined for the graph - the column is visible only when graph displays the non-live data (the parameter [Live data](#) is not checked or when user sets the past by button  **New time interval**)
- *Sum* - sum of all valid object values within the time interval defined for the graph

- *Weighted Average* - weighted average of all valid object values within the time interval defined for the graph
- *Arithmetic Average* - arithmetic average of all valid object values within the time interval defined for the graph
- *Last Value* - last object value
- *Auto Last Value* - last object value - the column is visible only when graph displays the live data (the parameter [Live data](#) is checked) and graph changes because of new data are received
- *Universal* - content of the column is defined by the parameter [U.C.](#) in the object configuration or the function `%HI_SetGraphLineStat`

Note: For graphs containing live data (the parameter [Live data](#) is checked), there are evaluated all values within the time interval including last value. Last value of non-periodic data is not evaluated.

Custom colors

You can use global color settings for drawing the graph. The second alternative is to define your own color settings for the graph. To define them check **Custom colors** checkbox.

You can set a color of the window background, graph area, time axis and significant time. To select a color of corresponding part use the array of currently set color example. The [color palette](#) is opened after clicking at this array. Each change of a color is displayed in graph preview located right from the buttons.



Related pages:

[Configuration of graphs](#)