# **NMEA-0183**

# NMEA-0183 communication protocol

Supported device types and versions Communication line configuration Communication station configuration I/O tag configuration Errors and problems Geofencing - localization of position Literature Changes and modifications Document revision

### Supported device types and versions

This protocol supports the communication with GPS receivers that send data according to NMEA-0183 standard. It supports only data receive.

## **Communication line configuration**

- Category of communication line: Serial, SerialOverUDP Device Redundant or File I/O.
- · Parameters of Serial line are set according to setting of GPS equipment.

### File I/O communication line

The implementation of NMEA-0183 protocol supports the reading of files which contains NMEA packets/records. As NMEA-0183 records are text strings with CR-LF at the end, in one row of file must contain one NMEA-0183 record.

The files are searched in the directory according to the setting of parameter "Input file" on the tab "File I/O" in the configuration of line. The file must correspond to a mask according to the parameter "Filename Mask" in protocol of station. The file is analyzed (read) from top to bottom, after processing it is moved to the archive directory according to the setting of parameter "Archive directory" on tab "File I/O" in configuration of line. In this directory, the subdirectories with the time of creation or data analysis are created (see the parameter "Archive subdirectory time mask").

## Protocol line parameters

Dialog window of Line configuration - tab "Protocol parameters", choose the protocol **NMEA-0183**. They influence some optional parameters of protocol. You may set the following parameters for the line:

#### Table 1

Full name	Meaning	Unit / size	Default value
Archive Subdirectory Time Mask	A mask which is used to create the archive subdirectories for storing of the processed files (important only for File I/O lines). Use the following text string to set mask:: "yy" or "rr" - year (short format), "yyyyo" or "rrr" - year (long format), "mm" - month, "dd" - day.	-	yyyymm
Geofencing Polygons Definition File	Full path to a file which contain a definition of polygons (a localization of position in polygon - geofencing). Blank text switches of the localization feature. See the chapter Geofencing - localization of position.	-	-
Files Checking Period	Time period of loading of source directory.	mi:ss	01:00
Unknown Files Backup Directory	Backup directory for storing the unknown files.	-	-
After Processing Timeout	Delay after processing of file.	ss.mss	00.100
Future Data Filter	Time filter of data. If the time stamp of received data deviates from the current time by more than defined hours in the future, they are ignored. Set 0 (zero) to ignore the time filter.	hours	0
History Data Filter	Time filter of data. If the time stamp of received data deviates from the current time by more than defined days in the past, they are ignored. Set 0 (zero) to ignore the time filter.	days	0
Additional Error Logfile	Additional error log file for tracing communication errors	-	-

#### Communication station configuration

· Communication protocol "NMEA-0183".

- As for Serial and SerialOverUDP Device Redundant lines (i.e. asynchronous serial communication), the address parameter is not required (blank text). The protocol NMEA-0183 does not support the addressing of devices. Data are sent spontaneously. Only one device may be connected to one serial asynchronous communication line.
- As regards File I/O line, the address may be any text string. It can be used for searching of the file with NMEA data for the given station (see the parameter "Filename Mask" on protocol of station).

# Station protocol parameters

Dialog window for configuration of station - tab "Protocol parameters".

They influence some optional parameters of protocol. You can set the following parameters:

#### Table 2

Full name	Description	Unit / size	Default value
Maximum Wait Retry	Retry count of reading response till its completion.  Maximum retries of reading of line so that the NMEA packet/record is complete (it is relevant only for Serial and SerialOverUDP Device Redundant lines).	-	40
Wait Timeout	Delay between the readings of line until NMEA packet/record is complete (it is relevant only for Serial and SerialOverUDP Device Redundant lines).		
Position Data Format	Conversion of data of geographical position from NMEA records GPRMC.3, GPRMI.1, GPGGA.2, GPGLL.1, PGRMF.6 for latitude and GPRMC.5, GPRMI.3, GPGGA.4, GPGLL.2, PGRMF.8 for longitude. You can choose "deg/min" (initial form of NMEA, the same value as it has been read) or "deg" (conversion to degrees).		deg
Speed Units	Conversion of data about speed to required technical unit (GPRMC.7 and GPVTG.3 in knots, GPVTG.4 and PGRMF.12 in km/hour).		knots
Trace Received Data	Show information about received raw data.		YES
Trace Received Values	Show details about analyzed values of I/O tags.	YES/NO	YES
Filename Mask	Mask for searching of files with NMEA information (it is important only for File I/O). Mask must be a text string with support of special items in braces {}: {NN} - address of station, 'N' character count must be equal to the length of station address, {yyyy} or {yy} - year (short/long format), {mm} - month (1 to 12), {dd} - day (1 to 31), {hh} - hour (0 to 23), {mi} - minute (0 to 59), {ss} - second (0 to 59).  Digit placeholder '** may be used also at any position in mask. Examples: nmea_data.* nmea_data.* nmea_data*txt nmea_data*(NNN).txt nmea_data*(NNN).txt nmea_data*(NNNN).txt station_(NNNNNN)*	-	
Synchroniz e Time Delta	Positive value activates the correction of system time from GPS data. If the difference between the system time and time received from GPS is greater than value of this parameter (in miliseconds), a task that adjusts system time will be started. Time will be adjusted in small steps to avoid a sudden time-jump which is usually undesirable.  Default value of this parameter is 0 and it means that time synchronisation is disabled.	ms	0
Long Difference Time	If absolute value of a computed time difference between GPS time and system time is greater than parameter Long Difference Time then the correcton of system time will not be started immediately. Instead KOM detects whether this difference is repeated at least Long Difference Count times consecutively. If it does and if absolute value of difference of consecutive time differences is not greater than Long Difference Time then the correcton of system time will be started.  Parameters are meant as a protection of random occurrence of "out of range" time. Value 0 of parameter Long Difference Time disables this protection.		0
Long Difference Count			0
Align To Minutes	KOM process publishes only the values received on the edge of new minute (sec = 0). For proper functionality, the polling period must be less than one minute.	YES/NO	NO
External Command File	Full path to the external command file which is called with the defined period. Empty text string means that the external command file is not used.	-	
External Command Period	The period for calling external command file. If the value is 0 seconds, the command file is called always before data reading from the particular station.		
Call External Command Synchronou sly	Call external command file synchronously (YES) or asynchronously (NO).	YES/NO	YES

# I/O tag configuration

Allowed types of I/O tags: Ai, Ci, Di, TiA, TiR, Txtl.

The address of I/O tag is in the format:

#### SSSSS.I

SSSS - the identification of NMEA record (e.g. "GPRMC")

I - an index of the order of data in NMEA record. The index is a positive integral number. 0 = the index of identifier of NMEA record, 1 = index of the first value

You can configure a special I/O tag **Ci** or **Ai** with address **\$POLY**, which acquires the value of a polygon code, in which was localized the current position. See the chapter Geofencing - localization of position.

You can fined the examples in the table 3.

#### Table 3

Address	Value type	Description
GPGGA.7	Ci	Number of located satellites.
GPRMC.3	Ai	Latitude.
GPRMC.4	Ci	Latitude hemisphere, it takes the values 78 (N) or 83 (S).
GPRMC.4	TxtI	Latitude hemisphere, it takes the values "N" or "S".
GPRMC.5	Ai	Longitude.
GPRMC.6	Ci	Longitude hemisphere, it takes the values 69 (E) or 87 (W).
GPRMC.6	Txtl	Longitude hemisphere, it takes the values "E" or "W".
GPRMC.1	TiR	Time.
GPRMC.9	TiA	Date.

The implementation of protocol requires the receive of NMEA packet/record "GPRMC" (Recommended Minimum Specific GPS/TRANSIT Data). From time data UTC date/time is created a time stamp in this packet. This time stamp is changed from UTC to the local time and then is used to assign the time stamp (value time) in all values of I/O tags.

## Geofencing - localization of position

If the file with the definition of polygons is loaded successfully, the localization of position in polygon is activated. The file format is following:

[meno\_polygónu1,kód\_polygónu1] latitude1 <tab> longitude1 latitude2 <tab> longitude2 latitude3 <tab> longitude3 .... latitudeN <tab> longitudeN [meno\_polygónu2,kód\_polygónu2] latitude1 <tab> longitude1 latitude2 <tab> longitude2 latitude3 <tab> longitude3 .... latitudeN <tab> longitudeN

The definition of polygon starts with a name and an unique integer code of polygon in the first row. It is followed by all the known border positions of polygon. The border positions of polygon are the numerical data of *latitude* and *longitude* separated by tab. You can define 100 polygons at the most in this file.

A simplified example of the file with the definition of polygons:

[SVK,1]
49.510531 18.597243
49.508383 18.56925
49.500642 18.544688
49.490084 18.53395 [CZ,2]
49.517426 18.85232
49.516242 18.812956
49.504529 18.778742
49.502553 18.710839
49.507645 18.675815
[PL,3]
50.870486 14.82294
50.869251 14.839542
50.876814 14.867844
50.867136 14.896914

If the localization of the current position, which was gain from the communication in some of polygons, the I/O tag with the address \$POLY acquires the value of proper polygon code. The position is searched from the top and from the first definition in the file and ends with the first successful finding of position. If the localization fails, the polygon code 0 is set. Therefore the value (0) is not permitted in the definition of polygon codes.

# **Errors and problems**

The error messages, mentioned below, may occur during the start or communication. It is recommended to activate the monitoring of communication in the configuration of line for easier identification of problem. You can choose it from these levels:

- Monitor (at least)
- Monitor & Disk (recommended)

• Disk (recommended)

When you set "Monitor & Disk" or "Disk", the file "line\_name.LOG" occurs in the subdirectory "\TRACE" in application directory on the computer with the running communication process. This file contains all the debug and error messages.

Error:	Unsupported mask item 'maskitem'!
Description:	Unsupported item in the mask file that searches the files for loading.
Error:	Cannot open file 'FileName' !
Description:	The opening of the file for reading failed.
Error:	Unconvertible value: 'ValueString' for I/O tag 'I/O tag_name'!
Description:	The value, received from NMEA packet/record, cannot be converted on the value of I/O tag.
Error:	Unconvertible value: 'ValueString' for I/O tag 'I/O tag_name', unsupported type value_type!
Description:	Value type of I/O tag is not supported.
Error:	Error in address, I/O tag_name', Address: 'PointAddress' !
Description:	Address of I/O tag does not correspond to the required format.
Error:	Checksum ERR! Received=XX, Expected=YY
Description:	Invalid checksum in the received packet.
Error:	Cannot open geofencing polygons definition file 'filename'!
Description:	The file with polygon definition, the value of line parameter "Polygons definition file", has not been found.
Error:	Problems detected in geofencing polygons definition file 'filename'!
Description:	The file with polygon definition, the value of line parameter "Polygons definition file", does not correspond to the required specification and was ignored.
Error:	Error during geofencing position detection for I/O tag 'I/O tag_name'!
Description:	Upon detection of position in polygon occurred unexpected error. The polygon code is invalid.

### Literature

- http://www.nmea.orgReference books for Garmin http://www.garmin.com

# **Changes and modifications**

- August 21, 2009 localization of position in polygon.
  February 19, 2015 added new parameter to station parameters.

# **Document revisions**

- Ver. 1.0 February 8, 2008 document creating.
  Ver. 1.1 March 13, 2008 modification of protocol parameters.
  Ver. 1.2 August 21, 2009 updating of document.
- ver. 1.3 February 19, 2015 added new parameter to station parameters.



Related pages:

Communication protocols