

# HI\_GetMetadata

## %HI\_GetMetadata, %HI\_SetMetadata functions

### Function

**%HI\_GetMetadata** function gets back (according to the defined key) text value of metadata that are assigned to a graphic object.  
**%HI\_SetMetadata** function sets (according to the defined key) a text value of metadata that are assigned to a graphic object.

### Declaration

```
TEXT %HI_GetMetadata(
    INT in _refId,
    TEXT in _key
)

BOOL %HI_SetMetadata(
    INT in _refId,
    TEXT in _key,
    TEXT in _value,
    BOOL in _bOverWrite
)
```

### Parameters

<u>_refId</u>	Reference to graphic object ( <a href="#">reference variable</a> ).
<u>_key</u>	Key which specified metadata.
<u>_value</u>	New value of metadata.
<u>_bOverWrite</u>	TRUE - either metadata are inserted (if they do not exist) or the value of existing metadata is updated. FALSE - either metadata are inserted (if metadata do not exist) or the existing value of metadata is kept.

### Description

**%HI\_GetMetadata** gets back (according to the set key) text value of metadata which is assigned to graphic object.  
**%HI\_SetMetadata** sets new metadata to the graphic object according to defined key.

### Note 1

Configuration of [metadata](#) for graphic object.

**%HI\_SetMetadata** function applies the change of metadata only on the running instance of picture.

### Note 2

These functions are available also in [%HIX\\_ version](#).



#### Related pages:

[Graphic object manipulation functions](#)  
[Function arguments - types](#)