

Control the Analog and Integer Output I/O Tags (AO, CO) (HI /Monitoring and Controlling of D2000 System Objects/Old Control Windows)

Controlling analog and integer outputs (AO, CO)

!!! OLD CONTROL WINDOWS !!!

Clicking a graphic object with an analog output I/O tag (AO) or integer output I/O tag (CO) connected to control (the user has insufficient access rights) opens the following control window.

If there are defined status texts for given object, then the window has an alternative appearance to set values. See: [Controlling Objects with Defined Status Texts](#).

1	Object name.
2	Object description.
3	Current value [states] and technical units of the object.
4	Time when the objects has got the current value.
5	Flags (attributes) of the object value. There are displayed the names of flags, value of which is TRUE.
6	Range defined for the object: <VLL, LL, HL, VHL>. VLL - Very Low Limit (the lowest limit) LL - Low Limit HL - High Limit VHL - Very High Limit (the highest limit)
7	Button to control process alarms.
8	Acknowledge the object value.
9	Acknowledge the process alarm.
10	Part of control window intended for output control .
11	Part of control window intended to set a default value .

Default value of analog and integer outputs (AO, CO)

Checking **Use default value** box allows to use a default value. Control window will be enhanced with the control buttons allowing to control a default value. I/O Tag value can be replaced with a value of another object (so-called control object), or can be set manually by operator of process [D2000 HI](#) in the following part of control window.

1	Input edit box to enter an object default value.
2	Sliding scale to set an object default value.
3	Set flags (attributes) of the object default value.
4	Current value and state of control object of the default value.
5	Depending on the Execute button, the Set buttons perform two possible functions: 1. The Execute button is not placed in the window. Clicking the Set button will set the defined default value along with object value flags (attributes). 2. The Execute button is placed in window. Clicking the Set button only "prepares" the defined default value along with value flags (attributes) to set.
6	This button is placed in window if Acknowledge option has been enabled at link configuration of the graphic object in the process D2000 GrEditor . Clicking Execute button will set the defined default value along with value flags (attributes) that have been "prepared" to set by clicking Set button.
7	Switch default value mode into automatic mode. Default value in this mode copies a value of control object.
8	Cancel the validity of the default value
9	Open a graph.

10	Insert the controlled object into current page of opened Browser. If Browser is not opened, clicking on this button will open it and the controlled object will be inserted into its first page.
11	Close the control window.

Output control

Analog and cardinal output value can be controlled by a value of another object (so-called control object) or it can be set manually by operator of process [D2000 HI](#) in the following part of control window.

1	Input edit box to enter an object default value.
2	Sliding scale to set a default value of the output object.
3	Set flags (attributes) of the object default value.
4	Current value and state of control object of the default value.
5	Depending on the Execute button, the SET buttons perform two possible functions: <ul style="list-style-type: none"> 1. The Execute button is not placed in the window. Clicking the Set button will set the defined output object value along with value flags (attributes). 2. The Execute button is placed in the window. Clicking the Set button only "prepares" the defined output object value along with value flags (attributes) to set.
6	This button is placed in window if the Acknowledge option has been enabled at link configuration of the graphic object in the process D2000 GrEditor . Clicking the Execute button will set the defined output object value along with value flags (attributes) that have been "prepared" to set by clicking the Set button.
7	Switch output object value mode into automatic mode. Default value in this mode copies a value of control object.