
Configuration process

D2000 System Configuration Guide

To start the configuration guide, click on the file D2Install.exe in the directory that has been created when creating a new instance.



A structure of the configuration tool is similar to the installer. You may use the "Next" and "Back" buttons when you go through the configuration dialog windows. The "Install" button runs the final configuration.

At first, you have to specify the input configuration file in the initial window. There are two files you may choose - the default configuration file or own file.

The default configuration file D2install.xml contains the default settings of system. This file is used when choosing the option "Default configuration".

The configuration tool enables both the manual and automatic configuration. When you click on "Next" button, the **manual configuration** will be done. It means, the user is guided through all the necessary dialogs in which he may specify the system settings.

The "Install" button starts the **automatic configuration** according to chosen configuration. The user cannot change the configuration parameters. There will be used those from the defined configuration file.

A user has three options:

- 1. Use the default configuration (D2install.xml) and manually pass the configuration guide.
- 2. Specify own configuration file and manually pass the configuration guide.
- 3. Specify own configuration file and automatically configure D2000 System without the guide.

When selecting the automatic configuration, all the steps that configure the system are skipped and the final configuration is started (see the section "Final configuration").


All the steps below will be done, when selecting the manual configuration.

Manual configuration

In the installation guide you could chose one of the following types of installation:

- Server
- Client:
 - Basic
 - o Developer
 - Remote


Each type of installation requires the different system settings. Therefore, the installation guide is different for each installation. The steps of configuration depend on the type of installation and the marked parameters in the single dialog boxes.



Each rectangle represents one or more configuration catalogs for the setting of system parameters. The configuration proceeds according to the arrows. The upper point represents the start position, i.e. the configuration dialog in which you have to choose a type of installation. The end point represents a final configuration as per the settings.

Configuration guide

1. Basic settings (all types of installation)



In this dialog window, you define the mask of network and the path to the basic directories necessary for the D2000 System operation:

- Application the directory to which all files necessary for application will be stored.
- Logging the directory that will contain the information about the process activity.

This dialog allows to set type of licence used in D2000 System.

Type of licence


Allows to choose one of the following items:

- Demo
- Basic
- Standard
- Enteprise

Licence file

If a user enters a license file, it is copied to the correct location. Selecting a license file is not required, in case of a license type Demo is not available at all.

2. Server settings (Server)



Support programs


The options define which support programs, necessary for running of some parts of D2000 System, are to be installed. If some of the options is checked, this program will be installed after finishing the configuration. If some of the items is checked and disabled, the given program is installed on the computer and need not be installed again.

Use hardware keys / Use software keys

Specifies the type of license keys that will be used for authentication in D2000 System.


3. Connection settings (Client)

It requires to set the connection to D2000 Server. It is either **IP/Computer name** or **name of redundant group**. This setting is determined for all configured clients.




4. Client settings (Client)

This dialog window enables to define which support programs are to be installed for the client processes. It is the support for HW keys.




5. Creating the shortcuts (Client)

In this dialog window user may set the shortcuts of the important processes of D2000 System and their placement. The final configuration will contain all links that are checked in the column "Add shortcut". If any parameter is not checked, no shortcut will be created in the computer.




Double click on the particular client process opens the dialog window in which user may change its relative location ("Name" item) and the start parameters ("Parameters" item).




6. Remote client settings (Remote client)

Next step enables to configure the remote processes of D2000 System. If you check the checkbox in the "Install" column means that the given process will be created.




Double click over the remote client to open the configuration dialog box, in which the user may set next parameters.



The detailed parameters of remote client are described in the D2000 System Configuration Reference Manual.

Confirming a configuration

Before the final configuration, you must confirm the configuration.




The user may start the application or save the final configuration file for further usage.

Regardless of user decision, the final configuration is always stored to the folder D2Install in a target directory where is an instance of installation.

Final configuration

The final configuration is done automatically. In the dialog window, the user can see the information about each step of configuration. It also displays the information about the success or failure of the given step.



After finishing the configuration, the **Complete** button to close the guide is enabled. In this step the instance of D2000 System is installed, configured and ready for use.



Related pages:

D2Install - D2000 System Configuration Guide