

XML_ExportD2ObjToDocument

%XML_ExportD2ObjToDocument function

Function

The function exports an object from configuration to XML document.

Declaration

```
INT %XML_ExportD2ObjToDocument (  
    HBJ in objID,  
    TEXT in eportSettings  
)
```

Parameters

objID	The value of HBJ or INT type which represents the unique identifier of object (HOBJ).
exportSettings	XML Export settings (optional parameter) in form [setting={on/off} [setting={on/off} [...]]].

Return value

Handle to the open XML document.

Description

The function asks the process [D2000 Server](#) to export the object (according to unique identifier of the object (HOBJ) which has been entered by parameter objID) to XML documents. If specific object does not exist or the parameter represents invalid value, the function will get back the invalid value.

Example

```
INT _doc  
  
_doc := %XML_ExportD2ObjToDocument (_hbj)
```

```
INT _doc  
  
_doc := %XML_ExportD2ObjToDocument (Sec\HBJ, "zero_hobj=off exp_logs=on")
```

Note

Error description can be called by means of ESL function [%XML_GetLastErrorMessage](#) (if the function gets back the invalid value).



Related pages:

- [XML file manipulation functions](#)
- [Function arguments - types](#)