

# HI\_GetOwnerInstance

## %HI\_GetOwnerInstance function

### Function

The function **%HI\_GetOwnerInstance** returns an instance of the picture which a current picture is inserted as a subpicture to.

### Declaration

```
INT %HI_GetOwnerInstance(
    [BOOL in bPhysical := True]
)
```

### Parameters

#### bPhysical

If the value of parameter is **True**, the function returns the instance number of the picture which the current picture is inserted to.  
If the value of parameter is **False**, the function returns the required instance number of the picture which the current picture is inserted to.

### Description

If the picture is not opened as a subpicture, the return value is 0.

### Example

```
ENTRY btn_OnClick
    _ownerHBJ := %HI_GetOwnerHBJ()
    _ownerInstance := %HI_GetOwnerInstance()
    CALL [(_ownerHBJ)] Entry(_i) SYNC ON _FROM_HIP INSTANCE _ownerInstance
    _i := _i + 1
END btn_OnClick
```

The example shows a called RPC procedure *Entry* of the picture, which current picture is placed to.

### Note 1

See also [%HI\\_GetOwnerHBJ](#).

### Note 2

This function exists also in [%HIX\\_ version](#). It enables to find out HBJ also from other pictures than the current subpicture. HIX function works unless the picture, addressed via [hobj, instanceId], contains ESL script.



### Related pages:

[Active picture manipulation functions](#)  
[Function arguments - types](#)