

Unblock (Work with D2000 HI)

Unblock alarms

Unblocking blocked alarms allows operator to unblock an alarm (selection of alarm). When an alarm is in **Blocked** state, the status of the alarm object may not be changed into other state while the alarm is not unblocked by operator.

To unblock an alarm

1. In the [Alarm list](#) window (3rd tab - Blocked alarms), select the alarm (selection of alarms) to unblock.
2. Click the button **Unblock**.

The alarm will be evaluated immediately after unblocking. It means that the alarm in **Blocked** status will changes its status into one of **Normal** or **Alarm** states according to the evaluation of conditions to raise and finish alarm, that have been defined at the object configuration.

Unblocked alarm will be displayed either in the list of critical alarms or uncritical alarms (according to the configuration).



Related pages:

[Controlling blocked alarms](#)