Script Debugging (Script Configuration)

Script debugging

To debug a script, use the Script editor which can be opened as follows:

- for objects of Event type from the D2000 CNF process
- for active pictures from the D2000 GrEditor process

The only requirement to start debugging a script is the following:

- for objects of Event type the D2000 Event Handler process (the parent of the corresponding object of *Event* type) must be running
 for active pictures the D2000 HI process must be running with the corresponding picture opened in it

After switching the script to the debug mode it is necessary to wait for suspending the execution of script actions. Then you can monitor:

- the execution of script actions
- the values of local variables

The toolbar of the Script editor contains the following buttons used to debug a script:

Button	Description
Start	event - Starts the event instance and stops before the first action is executed active picture - disabled for active pictures
Stop	Stops the script debugging. If the debugging has been started by clicking the button (<i>Start</i>), clicking the button stops the script execution and a forced termination log will be written into the log database. If the debugging has been started by clicking the the formation (<i>Attach to the running script</i>), the given instance keeps the execution of script actions.

\odot	Wait for launch		
	Skip times before start debug:	3	
	Only for instance:	2	
		OK Cancel	
The script is		ber of starts is reached. The	number includes either all script
of instance -	the parameter Only for instance is not enabled) or j an instance number specified).	ust the script of defined insta	nce (the parameter Only for ins
For a selection option (buttor	on of the specific D2000 Event or D2000 process intr	ended for ESL script debuggi	ing push the SHIFT button and c
- Wait for L - Attach to	aunch ⁻ unning script		
- Wait for L - Attach to The window t	aunch ^r unning script used for process selection for debugging opens after	this.	
- Wait for L - Attach to The window	aunch ^r unning script used for process selection for debugging opens after	this.]
- Wait for L - Attach to The window to	aunch running script used for process selection for debugging opens after Select process for debugging	this.	
- Wait for L - Attach to The window t	aunch running script used for process selection for debugging opens after Select process for debugging Process:	this.	
- Wait for L - Attach to The window	aunch running script Jsed for process selection for debugging opens after Select process for debugging Process: SELF.EVH OLOCAL	this.	
- Wait for L - Attach to The window	aunch running script used for process selection for debugging opens after Select process for debugging Process: SELF.EVH O LOCAL REMOTE	this.	
- Wait for L - Attach to The window	aunch running script Jeed for process selection for debugging opens after Select process for debugging Process: SELF.EVH O LOCAL REMOTE	this.	

List of instances							×	
Instance Info	НОВЈ	D2000 Server instan	Internal instance	User	User des	Outdated configura		
1	268173310	1	10150	s	Test User			
2	268173311	2	10158	s	Test User			
123	268173312	10008	10170	5	Test User			
						ОК	ancel	
Instance	Logical	nstance numbe	r - the instance	number th	e object ha	s been open wit		
Instance	Logical i Instance function	nstance numbe number can be s.	r - the instance retrieved by th	number th	ne object ha etSelfInstand	s been open witl celd (for active p	n. ictures only) or %	GetSe
Instance Info	Logical i Instance function	nstance numbe number can be s. emented yet.	r - the instance retrieved by th	number th	ne object ha etSelfInstand	s been open witl celd (for active p	n. ictures only) or %	GetSe
Instance Info HOBJ	Logical i Instance function Not impl Object ir Instance	e number can be s. emented yet. hstance HOBJ. e number can be	r - the instance retrieved by th e retrieved by th	number the %HI_Ge	e object ha etSelfInstance elfHBJ functi	s been open with celd (for active p	n. ictures only) or %	GetSe
Instance Info HOBJ D2000 Server instance	Logical i Instance function Not impl Object ir Instance Physical GetSelfI	Instance numbe e number can be s. emented yet. Instance HOBJ. e number can be l instance numb instance numb	r - the instance e retrieved by th e retrieved by th er of the object er can be retrie ons.	number the %HI_Ge ne %GetSe in D2000 eved by the	elfHBJ functi system - us	s been open with celd (for active p on. ed by the process elfInstanceId (fo	n. ictures only) or % ss D2000 Server. r active picture on	GetSe
Instance Info HOBJ D2000 Server instance Internal instance	Logical i Instance function: Not impl Object ir Instance Physical GetSelfI Instance Its value	Instance numbe e number can be s. emented yet. Instance HOBJ. e number can be l instance numb I instance numb nstanceld functi e number used b is can be retriev	r - the instance e retrieved by th e retrieved by th er of the object er can be retrie ons. ny the script int ed by the %Ge	number th ne %HI_Ge ne %GetSe in D2000 eved by the erpreter - a tEventInst	elfHBJ functi system - us %HI_GetS n internal u	s been open with celd (for active p on. ed by the process elfInstanceId (fo nique identifier. ion.	n. ictures only) or % es D2000 Server. r active picture on	GetSe
Instance Info HOBJ D2000 Server instance Internal instance User	Logical i Instance function Not impl Object in Instance Physical GetSelfI Instance Its value	Instance numbe e number can be s. emented yet. Instance HOBJ. Instance numb Instance numb Instance numb Instance d functi e number used b is can be retriev r under which th	r - the instance or retrieved by the er retrieved by the er of the object er can be retrieved ons. by the script intend by the %Generic er instance is retrieved by the script of the	number th ne %HI_Ge ne %GetSe : in D2000 eved by the erpreter - a itEventInst	elfHBJ functi system - us %HI_GetS n internal u	s been open with celd (for active p on. ed by the process elfInstanceId (fo nique identifier. iion.	n. ictures only) or % ss D2000 Server. r active picture on	GetSe

Related pages:

Stepping Local variables (Watch) Stepping options