

# XML Export settings (HI)


## XML Export settings

Parameters for XML Export **are used by all the processes running on the computer.**

The parameters can be set through the following processes:

- **D2000 CNF** - from the main menu **System \ XML Export settings ...**
- **D2000 GrEditor** - from the main menu **Settings \ XML Export settings ...**
- **D2000 HI** - from the main menu **System \ XML Export settings ...**

The following dialog box will open:



The dialog box titled "XML Export settings" contains the following elements:

- XML Export settings** section with a list of checkboxes and corresponding dropdown menus:
  - ☐ Recursive export with all child objects: WITH\_CHILD
  - ☐ Recursive export with all referenced objects: WITH\_REFER
  - ☐ Export with all direct referenced objects: WITH\_DREFS
  - ☐ File time = modify time of exported object: FILE\_TIME
  - ☒ Check configuration of objects before export: CHECK\_EXP
  - ☐ Set ID to 0 in exported files: ZERO\_HOBJ
  - ☐ System objects and variables will be exported: SYS\_VARS
  - ☒ Set encoding to utf-8 in exported files: UTF8\_ENC
  - ☐ Exported objects are not strict required in groups: GROUP\_SOFT
  - ☐ Objects are exported to "export subdir" of object: SUBDIR\_EXP
  - ☒ Object life logs are exported with objects: EXP\_LOGS
  - ☐ Change dimension of struct. var. with param. dim.: NORM\_D2REC
  - ☐ Null parametrized configuration properties: NULL\_PAMED
  - ☐ Export XML files for data comparison: EXP\_PURE
- Folder for XML Export** section with a text box containing "D:\D2000\D2000.APP\nova2\XML\_Export\" and a browse button (...).
- Bottom section with two checkboxes:
  - ☐ Automatic XML Export after object save
  - ☐ Automatic XML Export to subdirectory according to user name
- Buttons: OK and Cancel.

## XML Export settings

Setting of export parameters for XML Export.

## Folder for XML Export

Text box to write the path. If the particular path is not entered, the default folder is XML\_Export in the application directory.

## Automatic XML Export after object save

If the option is checked off the object will be automatic exported to directory for XML Export after each saving of object configuration or after import of the object from the client process. This option is available only if the option XML Repository in active status is not checked off.

## Automatic XML Export to subdirectory according to user name

If the option is checked off, the objects will be exported into subdirectory of the directory for XML Export. The name of this subdirectory is the same as the name of logged in user.

This option is available only if the option **Automatic XML Export after object save** is checked off.

**Button** 

Selection of the directory.

Click on button "**OK**" to confirm the setting of parameters.