


Acknowledge (Work with D2000 HI)

Acknowledge alarms

Acknowledging alarms means confirmation of current alarms (alarm object in Alarm state) by the operator. Acknowledgement of an alarm changes its status to a **Normal** state. But you can also acknowledge the next alarm state – Unacknowledged. This state occurs for an *Alarm* type object which is defined as an acknowledgement-required alarm at its configuration in the [D2000 CNF](#) process, when the condition to raise alarm is not met.

To acknowledge an alarm

1. In the [Alarm list](#) window (1st or 2nd tabs), select an alarm (or a selection of alarms) in *Alarm* or *Unacknowledged* states.
2. Click the button **Acknowledge**. The alarm may be acknowledged by double-clicking its name or by pressing the Spacebar key.

Alarm acknowledgement is presented by the change of the alarm graphic symbol to  symbol. In case the acknowledged alarm is the last active one in the system then the visual and audible alert will stop after its acknowledgement.



Related pages:

[Controlling active alarms](#)
[Unblock blocked alarms](#)
[Graphic alarm symbols](#)