

Teltonika Codec14

Teltonika Codec14 communication protocol

[Supported device types and versions](#)

[Communication line configuration](#)

[Communication station configuration](#)

[I/O tag configuration](#)

[Literature](#)

[Changes and modifications](#)

[Document revisions](#)

Supported device types and versions

The communication protocol Teltonika Codec14 supports data acquisition from the "Fleet Management Systems Unit" Teltonika devices of type FM4200 with firmware by Movys.

The protocol represents a TCP server to which the units are being connected online. The data come into the system via configuration of the so-called "master" station and I/O tags. I.e. whatever number of connected units send data to the system via one sample configuration of the unit. A unique IMEI code of the unit identifies data from single units.

Communication line configuration

- Communication line category: **TCP/IP TCP**.
- Server host: **all** or * (TCP server), server port: well-known port according to the setting of the device.

Communication station configuration

Communication protocol: **Teltonika Codec14**.

Recommended setting of the station time intervals: delay 1 sec.

Station protocol parameters

Following station protocol parameters can be configured:

Table 1

Full name	Meaning	Unit	Default value
Clients per Thread	A number of the connected units handled by one thread. It is used for balancing the power and the response of communication process in dependence on the number of connected units.	1 up-to 200	50
Send Async Message Request After Connect	KOM process will send 'Asynchronous Message Request' after a unit is connected. The unit will answer by 'Asynchronous Message Response' which contains the data (AVL record).	YES /NO	YES
Debug Packet Analyse	Activation of debug information about the received and sent datagrams.	YES /NO	YES
Debug Values	Activation of debugging information about received values.	YES /NO	NO
Debug Packet Queue Flow	Activation of debugging information about the state of received data processing by D2000 System.	YES /NO	NO
Debug Packet Binary Contents	Enabling of debug listings containing the received/sent datagrams in binary form.	YES /NO	YES

Unit Debug File	<p>Enabling of a special form of tracing the units when the debug information is saved into a special file. The name of this file is derived from the IP address of the unit (IP1_IP2_IP3_IP4.log) in the "trace" subdirectory of the application directory. It makes easier the identification of debug lists from the unit.</p> <p>Meaning of parameters:</p> <table border="1"> <tr> <td>Not_Allowed</td> <td>- the file will not be created</td> </tr> <tr> <td>Both Line & Station</td> <td>- the file will be created in parallel with the standard .log file which traces the communication line</td> </tr> <tr> <td>Station Only</td> <td>- only special log files are allowed Warning! This setting overrides the level setting of communication tracing in the line configuration (see also the information in document Communication lines - configuration dialog box, section Communication tracing).</td> </tr> </table>	Not_Allowed	- the file will not be created	Both Line & Station	- the file will be created in parallel with the standard .log file which traces the communication line	Station Only	- only special log files are allowed Warning! This setting overrides the level setting of communication tracing in the line configuration (see also the information in document Communication lines - configuration dialog box, section Communication tracing).	Not Allowed	Not Allowed
Not_Allowed	- the file will not be created								
Both Line & Station	- the file will be created in parallel with the standard .log file which traces the communication line								
Station Only	- only special log files are allowed Warning! This setting overrides the level setting of communication tracing in the line configuration (see also the information in document Communication lines - configuration dialog box, section Communication tracing).								
Unit Debug File Size	Maximal size of the special debug file of unit tracing. After the file reaches this size, it will be renamed and saved like the file of communication line tracing.	1 up-to 50 MBytes	10						

I/O tag configuration

Possible value types of I/O tags: **Ai, Ao, Ci, Co, Di, Dout, TiA, ToA, TxtI, TxtO**.

List of I/O tag addresses

Table 2

Address	Meaning	Value type
HND.TRIG	Message handshaking - an issue of the new increment value signals the setting of all I/O tag values with the values of the received record and that they are ready to be processed.	Ci
HND.TRIG_ACC	Message handshaking - acknowledges that data was processed by the application. It is executed by the writing of value HND.TRIG and signals that the KOM process can create the next record.	Co
STAT.CONN_NR	Global Statistic - an actual number of the handled TCP connections.	Ci
STAT.IN_QUEUE_LEN	Global Statistic - number of received data files that are not sent to the system yet.	Ci
STAT.RD_TASKS_NR	Global Statistic - number of received threads.	
STAT.VIRT_ST_NR	Global Statistic - the actual number of connected units with a unique IMEI.	
UNIT_DATA.IMEI	Unit data - IMEI unit which data was received from.	TxtI
UNIT_DATA.DTIME	Unit data - timestamp of received data. The timestamp of the value of all I/O tags UNIT_DATA.xxx is identical.	TiA
UNIT_DATA.LAT	Unit data - latitude.	Ai
UNIT_DATA.LON	Unit data - longitude.	Ai
UNIT_DATA.ALT	Unit data - altitude (m).	Ai
UNIT_DATA.PRIO	Unit data - data priority (0/1).	Ci
UNIT_DATA.SAT	Unit data - number of the visible satellites.	Ci
UNIT_DATA.SPEED	Unit data - speed (km/h).	Ci
UNIT_EVENT.EvNr	Unit event - the value of the received events number <i>EvNr</i> . More detailed information on the events is mentioned in the literature about protocol Codec14 .	Ai/Di/Ci/TxtI
UNIT_DEBUG.DbgNr	Unit debug - debug information with index <i>DbgNr</i> . More detailed information on the events is mentioned in the literature about protocol Codec14 .	Ai/Di/Ci/TxtI
UNIT_STAT.ST_BYTES_IN	Unit statistic & info - number of the received bytes from the unit since the KOM process has been started.	Ci
UNIT_STAT.ST_BYTES_OUT	Unit statistic & info - number of sent bytes to the unit since the KOM process has been started.	Ci

UNIT_STAT. ST_CONFIG_TIM ESTAMP	Unit statistic & info - so-called config timestamp of the unit.	TiA
UNIT_STAT. ST_CONNECTED	Unit statistic & info - state of the connection (1-connected, 0-disconnected); only when the state is changed.	Ci
UNIT_STAT. ST_CONNECTS	Unit statistic & info - total number of the unit connections since the KOM process has been started.	Ci
UNIT_STAT. ST_FW_VER	Unit statistic & info - the version of the unit firmware.	TxtI
UNIT_STAT. ST_PACKETS_IN	Unit statistic & info - number of the received datagrams from the unit since the KOM process has been started.	Ci
UNIT_STAT. ST_PACKETS_O UT	Unit statistic & info - number of the sent datagrams to the unit since the KOM process has been started.	Ci
UNIT_RESTART. IMEI	Unit restart request - when the IMEI value is written into this I/O tag, a request to restart the unit with this IMEI is sent. If the writing failed, the unit is not connected.	TxtO
UNIT_MONITORI NG.IMEI	Unit monitoring request - when the IMEI value is written into this I/O tag, the request to monitor the unit with this IMEI is sent. If the writing failed, the unit is not connected.	TxtO
UNIT_ASYNCME SS.IMEI	Async message request - when the IMEI value is written into this I/O tag, a request to receive the asynchronous info from the unit with this IMEI is sent. If the writing failed, the unit is not connected.	TxtO
UNIT_DEBUG. IMEI	Unit debug request - when the IMEI value is written into this I/O tag, a request to receive the debug info from the unit with this IMEI is sent. The unit will respond by sending UNIT_DEBUG.DbgNr values. If the writing failed, the unit is not connected.	TxtO
UNIT_FW_UPD. PARAMS	Firmware update request - when the requested information is written, the process of firmware update for the unit with given IMEI is initialized. The format of data: <i>IMEI,APN,APNuser,APNpasswd,server:port,fw_filename</i> . More detailed information on the events is mentioned in literature about protocol Codec14 .	TxtO
UNIT_PARAMS_ OUT.IMEI	Unit parameters write messaging - IMEI of the unit which the changes of the configuration parameters are sent to.	TxtO
UNIT_PARAMS_ OUT.ADDR	Unit parameters write messaging - address of the written parameter (parameter ID).	Co
UNIT_PARAMS_ OUT.VALUE	Unit parameters write messaging - the value of the written parameter.	TxtO
UNIT_PARAMS_ OUT. VALUE_TYPE	Unit parameters write messaging - the value type of the written parameter.	Co

Parameter writing

The following rules hold:

1. The values of parameters can be only written, not read.
2. The check, if the writing was all right, is made through the so-called Configuration Timestamp (I/O tag with address UNIT_STAT.ST_CONFIG_TIMESTAMP). The value "Config Timestamp" must be set during the parameters writing - it is the parameter with ID = 0 (Profile Timestamp). The value should be the unique absolute time (the best is the time of the configuration start). After the parameters were written, the value UNIT_STAT.ST_CONFIG_TIMESTAMP must be set on the value of the parameter with ID=0 sent by the user.
3. Process of writing:
 - Set IMEI to I/O tag UNIT_PARAMS_OUT.IMEI, if it ends with error (on an action WAIT) the KOM process does not recognize the unit with this IMEI or it is not online.
 - Set the value type of parameter to UNIT_PARAMS_OUT.VALUE_TYPE (see the Table 3).
 - Set UNIT_PARAMS_OUT.VALUE with the value of the parameter (as text).
 - Set UNIT_PARAMS_OUT.ADDR with the parameter ID. The parameter ID=0 "Profile Timestamp" should be the first.
 - Set UNIT_PARAMS_OUT.VALUE_TYPE of next parameter.
 - Set UNIT_PARAMS_OUT.VALUE with the value of the next parameter.
 - Set UNIT_PARAMS_OUT.ADDR with the parameter ID of next parameter.

.... repeat as many times as many parameters you are writing. You need not write all the parameters but only those changed.....

 - Set UNIT_PARAMS_OUT.VALUE_TYPE to value 1 to finish the configuration.
 - Set UNIT_PARAMS_OUT.VALUE - empty text to finish the configuration.
 - Set UNIT_PARAMS_OUT.ADDR to value 0. It is a signal to send parameters into the unit physically.

Table 3

Type of value "UNIT_PARAMS_OUT. VALUE_TYPE"	Parameter ID "UNIT_PARAMS_OUT. ADDR"	Meaning
1	0	End of configuration.
2	x	Parameter of U8 type.
3	x	Parameter of I32 type.
4	x	Parameter of String type. It is allowed to use it for all the parameters except for the parameter with ID=0. The user is responsible for the text correctness, the KOM process does not check it.
6	x	Parameter of U16 type.
8	x	Parameter of Float type.
10	x	Parameter of U32 type.
11	0	Parameter "Profile Timestamp" - a text with absolute time in the form: "dd-mm-rrrr hh:mi:ss".

Literature

- Teltonika Codec.14 Communication Protocol Description, Rev.11.

Changes and modifications

- Sept. 2009 - Document creation

Document revisions

- Ver. 1.0 – September 30th, 2009



Related pages:

[Communication protocols](#)