

Databases - Configuration Dialog Box

Databases - configuration dialog box

Editing of all objects in the process [D2000 CNF](#) is being performed in the [configuration dialog box](#), a specific part of which is common for all editable objects and another part depends on the type of edited object.

Configuration dialog box of objects of *Database* type consists of several parts (tabs) containing similar parameters.

[General properties](#)
[Groups](#)
[Database](#)

General properties

Description

A text string describing the database. Maximum: 128 characters.
Possibility to use the [Dictionary](#) (to open press **CTRL+L**).

Database

DSN

ODBC Data Source Name (for [dbmanager.exe](#)) or Oracle TNS (for [dbmanager_ora.exe](#)).

User, Password

User name and password for accessing the database. The name and password will be used by the process [D2000 DBManager](#) while working with the database.

Test

The button allows testing the database connection functionality. Before running the test, it is necessary to click the button **Save**, if you performed any changes in the parameters **DSN**, **User** or **Password**.
The testing requires the running process [D2000 DBManager](#).

Test tables

This button allows testing the functionality of connection to the database. Providing that the connection to database is all right, the configuration of all objects of *Table* type is tested.
The testing requires the running process [D2000 DBManager](#).

Parameters

Additional parameters allow to optimize work of process [D2000 DBManager](#) (a process of D2000 system that makes databases accessible). For more details see [transaction work with database](#).

Brief description of individual parameters (more detailed is stated in the chapter [Optimization and debugging](#)):

- **Predefined connections:** number of database connections, which are created immediately after starting the process [D2000 DBManager](#) and will be kept open (optimization for slow opening of connects to some databases).
Note: starting with version 7.01.024 the object of Database type has an integer value equal to the current number of connections.
- **Maximum connections:** the maximum number of connections, that the process [D2000 DBManager](#) will create. Value 0 means an unlimited number of connections.
- **Maximum automatic connections:** the maximum number of non-transactional connections, which the process [D2000 DBManager](#) will create. For more details see [transaction work with database](#).
- **Reserved browser connections** - the maximum number of connections, which the process [D2000 DBManager](#) will reserve for working with browsers. Default value 0 means that no connections are reserved and non-transactional (automatic) connections will be used. For more details see [transaction work with database](#).
- **Close unused connections after (sec):** unused connections (above the number of predefined connections) will be closed after a given timeout. Until then they can be re-used.
- **Close DBManager after timeout (min):** if a database connection is blocked for a given number of minutes (database ODBC interface call does not return) e.g. because of a locked row in a table being accessed or because of database driver error, the internal watchdog will terminate the process [D2000 DBManager](#). Value 0 means that this feature is disabled.
- **Empty operations after inactivity period (min):** if a database connection is not used for a given period, an "empty" operation is executed on this connection. Executed operation is database-specific:
 - Oracle: SELECT 1 FROM DUAL
 - Sybase, MSSQL: SELECT 1
 - any other database: no operation

If the value of this parameter is not given or is 0, no "empty" operations will be executed (default).

In some cases, database servers or firewalls between them and DBManager cause the connections to be dropped after a defined inactivity timeout. "Empty" operation has been implemented to avoid such events and/or periodically detect other random breaks of connection during longer periods of inactivity.

- **Log operations longer than (sec)** - if a nonzero value is entered, the operations, the duration of which is longer than the entered seconds, are logged. See more information on logging in the section **Size of the log file** (below in the text) and [D2000 DBManager - debugging](#).
- **Debug**: debug info is displayed in the window of process [D2000 DBManager](#) and stored in a log file in the **TRACE** directory.
- **Size of the log file** - if a non-zero value is entered, operations executed in the database are not logged in the common log file of DBManager, but in the separate log file of the database. The maximum size (in MB) of the database log size is defined by this parameter. For more information see the section [DBManager - debugging](#).

Note: The D2000 system allows using 2 more debug levels through the process [D2000 System Console](#). The *Debug info* window opened for the process **D2000 DBManager** (e.g. *SELF.DBM*) contains the *DBG.DBMANAGER* and *DBG.DBMANAGER.DATA* debug categories besides the others. The *DBG.DBMANAGER* category enables recording detailed information (performed SQL commands) into the log file of the process and the *DBG.DBMANAGER.DATA* category enables recording the read and written values into the log file. Value times are recorded either in the local time if the database uses local time (see the parameter **Use monotonic time** described below) or the pure UTC (with the offset of 0) if the database uses monotonic time (see the parameter **Use monotonic time**). For more information see [Example](#).

- **Use monotonic time** - if the option is checked, there is an assumption that the database saves time items in monotonic time (no daylight-saving changes) and its offset from UTC/GMT time (London time) is a given number of hours. After getting values from the database, the process [D2000 DBManager](#) will adjust these values to local time (i.e. consider the offset and daylight-saving changes).
If the option is not checked, there is an assumption that the database saves time items in local time according to the settings of the Windows /Linux operating system where DbManager is running.
- **Off** - the parameter allows to "disable" the object (database).

Use: temporary stoppage of transaction work with the database (e.g. when creating an application there is no access to the database with predefined connections and the process [D2000 DBManager](#) is still writing errors when attempting to connect the database).

If user disables the database while the [D2000 DBManager](#) process is running, all following operations creating new connections (actions [DB_TRACE_OPEN](#)) or opening tables (actions [DBS*](#), [DB_CONNECT](#), [SQL_CONNECT](#), opening the [Browser](#) in the process [D2000 HI](#)) will be terminated with error and the local variable [_ERR_NR_TRANS_EX](#) is to be set to the value of 52 ([DBM_OFF](#)).

Transactions that use existing connections ([DB_READ](#), [DB_INSERT](#), [DB_TRANS_COMMIT](#), [DB_TRANS_CLOSE](#), [SQL_PREPARE](#), [SQL_FETCH](#), ...) will be still functional.

Starting with D2000 version 8.00.002 the predefined connections will not be created if the parameter **Off** is checked.

In the older versions of D2000, if the number of predefined connections is other than zero and the parameter **Off** is checked before running the process [D2000 DBManager](#), all predefined connections will be blocked until the user unchecks the parameter - the connections then begin to connect the database.

If a user disables the database during the run of process **D2000 DBManager**, predefined connections will not be terminated.

- **Maximum returned rows** - limits the maximum number of rows returned by actions [DB_READ](#), [DBS_READ](#), [SQL_FETCH](#), and [SQL_SELECT](#). If these actions intend to read more rows than specified by this limit and more rows than specified by this limit are available in the database, they will return a number of rows equal to this limit and the return code of the actions will be [_ERR_DATABASE_ROWS_LIMIT](#). Starting with version 7.02.012, this parameter limits (without causing an error) also the number of rows displayed by the [Browser](#) and used in the action [PG_CONNECT](#).

The default value of the parameter is 10,000 rows (if the defined number is lower or equal to 0). When reading a large number of rows (1000 rows or less, depending on the number of rows and type of data) we recommend using the actions [PG_READ](#) or [SQL_FETCH](#) in a loop - reading e.g. 100 rows at once. Reading and moving the data (SQL database --> D2000 DBManager --> D2000 Server --> D2000 Event) will be faster and consume less memory than moving one large structure.

The parameter is used as a protection from attempts to read a table containing a lot of rows - it can consume all free memory and crash the process [D2000 DBManager](#).



Related pages:

[Databases and Database Tables](#)