

HI_SetGraphLinePeriode

%HI_SetGraphLinePeriode function

Function

The function sets period width in a candlestick graph which is connected to displayer of [Graph](#) or [XY Graph](#) types ([Control function](#)).

Declaration

```
%HI_SetGraphLinePeriode(  
    INT in refId,  
    INT in lineNr,  
    INT in periode  
)
```

Parameters

refId	Reference to displayer (reference variable).
lineNr	Flow serial number.
periode	Period [s]

Description

The function sets period width which evaluates statistically an open, maximal, minimal and close value in the candlestick graph. If the period = 0, the graph looks like change one, i.e. a bar displays at each value change of the connected object.

Example

```
%HI_SetGraphLinePeriode(_Graph,1,3600)
```



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)