HI_SetColumnWidth

%HI_GetColumnWidth, %HI_SetColumnWidth functions

Function

The function **%HI_SetColumnWidth** sets the width of the specified column in the displayer of Browser or Logging type.

The function **%HI_GetColumnWidth** returns the width of the specified column in the displayer of Browser or Logging type (control function).

Declaration

```
%HI_SetColumnWidth(
   INT in refId,
   INT in index,
   INT in width
 )

 INT %HI_GetColumnWidth(
   INT in refId,
   INT in index
 )
```

Parameters

refId	Reference to a displayer (reference variable).
index	Serial number of column.
width	Column width. The parameter can contain optional values. The values of 0 and -1 set the column width as follows on condition that the index=0: • **0** - sets the column width by the texts in the column as well as the column header (it holds for all the columns) • **-1** - sets the column width by the texts in the column, text in the column header is ignored (it holds for all the columns)

Description

In **Browser**, the columns are configured in D2000 CNF, but in **Logging**, the sequence of columns is following:

Sequential numbers of Logging column:

1. Name
2. Description
3. Event_rising_time
4. User
5. Old_value
6. New_value
7. Priority
8. Incident
9. Log_type

Related pages:

Graphic object manipulation functions
Function arguments - types