Flow configuration (Displayers)

XY graph - Flow configuration



Description *

Description of the flow. Description is to be displayed in the descriptive table of the XY graph - the column **Name**. If no description is defined, the table cell will show an empty string. Description may be defined by means of the function %HI_SetGraphInfo from the picture script.

Units *

Technical units of the flow. Technical units is to be displayed in the descriptive table of the XY graph - the column **Units**. If technical units are not defined, the table cell will show an empty string. Technical units may be defined along with the description by means of the function %HI_SetGraphInfo from the picture script.

Draw

Flow drawing types:

- **Line** - show / hide the line
- **Fill** - show / hide the fill
- **Marker** - show / hide markers

Line type

Line type for links between flow values:

- **Straight**
- **Smooth**

Assigned axis

Selection of an axis that is to be assigned to the flow. Assigning an axis is performed by selection of corresponding axis number (from 1 to 20) from **Axis number** item.

Drawing
Style of drawing in regard of zero value on y-axis.

- **From X axis** - drawing starts from x-axis
- **Above 0** - drawing starts from 0 on y-axis upward
- **Below 0** - drawing starts from 0 on y-axis downward

Line color

Line color is defined by selection from the color palette opened after clicking the arrow button placed right from the color sample.

Fill color

Fill color is defined by selection a color from the color palette opened after clicking the arrow button placed right from the color sample.

The parameter is enabled, if the parameter Fill is checked.

Fill pattern

Fill pattern is defined by selection of a pattern from the patterns list opened after clicking the arrow button placed right from the pattern sample.

The parameter is enabled, if the parameter Fill is checked.

Marker color

Color of flow markers is defined by selection a color from the color palette opened after clicking the arrow button placed right from the color sample.
The parameter je is enabled, if the parameter Marker is checked.

Line

Selection of a line style (solid line, dashed line, ...).

The parameter **Highlighted** allows to draw thick line (doubled one).

Marker

Selection of a marker type.

The parameter **Highlighted** allows to draw markers of double size.

* The parameter cannot be configured in the process D2000 HI.

Related pages:

XY graph - configuration dialog box