

# HI\_GetColumnMasterVisible

## %HI\_GetColumnMasterVisible, %HI\_SetColumnMasterVisible functions

### Functions

The **%HI\_SetColumnMasterVisible** hides a column in the display of **Browser** type (overloads the function **%HI\_SetColumnVisible**) / cancels the overloading and enables to control the visibility of the column by the **%HI\_SetColumnVisible** function ([control function](#)).

The **%HI\_GetColumnMasterVisible** function gets the current status of overloading that is defined by **%HI\_SetColumnMasterVisible**.

### Declaration

```
%HI_SetColumnMasterVisible(
    INT in refId,
    INT in index,
    BOOL in bVisible
)

BOOL %HI_GetColumnMasterVisible(
    INT in refId,
    INT in index
)
```

### Parameters

<b>refId</b>	Reference to graphic object ( <a href="#">reference variable</a> ).
<b>index</b>	Column number.
<b>bEnable</b>	Visibility of column.

### Description

The **%HI\_SetColumnMasterVisible** function enables to hide the column in the display of **Browser** type - the parameter *refId* defines the name of the reference variable for **Browser**. When *bEnable* parameter is @FALSE, it overloads the **%HI\_SetColumnVisible** (disables its functionality).

The **%HI\_GetColumnMasterVisible** function gets the current status of overloading of column visibility which is set by **%HI\_SetColumnMasterVisible**. The return value @TRUE does not mean that the column is visible, but the column visibility is controlled by **%HI\_SetColumnVisible**. @FALSE means the functionality of **%HI\_SetColumnVisible** function is disabled and the column is hide.

The behavior of Master functions is described in the chapter **Master functions**.

### Example

```
ENTRY OnLogOn(IN TEXT _userName, IN BOOL _bLogOn)
    IF _bLogOn THEN

        ;when a user is logged on, the column is visible
        %HI_SetColumnMasterVisible(_Text,@TRUE)
    ELSE

        ;when a user is logged off, the column is hide
        %HI_SetColumnMasterVisible(_Text,@FALSE)
    ENDIF
END OnLogOn
```

### Note

This function is also in [%HIX\\_ version](#).



#### Related pages:

[Graphic object manipulation functions](#)  
[Function arguments - types](#)