

HI_GetColumnMasterEditable

%HI_GetColumnMasterEditable, %HI_SetColumnMasterEditable functions

Function

The **%HI_SetColumnMasterEditable** function disables to change a text in the column in the displayer of **Browser** type (overloads the function **%HI_SetEditEnable**) / cancels the overloading and enables to change the text in particular column as defined by the function **%HI_SetEditEnable** ([control function](#)).

The **%HI_GetColumnMasterEditable** function gets the current status of overloading that is defined by **%HI_SetColumnMasterEditable**.

Declaration

```
%HI_SetColumnMasterEditable(
    INT in refId,
    INT in col,
    BOOL in bEnable
)

BOOL %HI_GetColumnMasterEditable(
    INT in refId,
    INT in col
)
```

Parameters

refId	Reference to graphic object (reference variable).
col	Column in Browser.
bEnable	@TRUE - enables the graphic object @FALSE - disables the graphic object

Description

The **%HI_SetColumnMasterEditable** function disables to change a text in the column in the displayer of **Browser** type - the parameter *refId* defines the name of the reference variable for Browser. When *bEnable* parameter is @FALSE, it overloads the **%HI_SetEditEnable** function (disables its functionality).

The **%HI_GetColumnMasterEditable** function gets the current status of overloading of editing which is set by **%HI_SetColumnMasterEditable**. The return value @TRUE does not mean that the column can be edited, but the column fields are controlled by **%HI_SetEditEnable**. @FALSE means the functionality of **%HI_SetEditEnable** function is disabled and the text in the column object cannot be changed.

The behavior of Master functions is described in the chapter [Master functions](#).

Example

```
ENTRY OnLogOn(IN TEXT _userName, IN BOOL _bLogOn)
    IF _bLogOn THEN

        ;when a user is logged on, a text in column can be edited
        %HI_SetColumnMasterEditable(_Text,@TRUE)
    ELSE

        ;when a user is logged off, the access to a text in column is disabled
        %HI_SetColumnMasterEditable(_Text,@FALSE)
    ENDIF
END OnLogOn
```

Note

This function is also in [%HIX_ version](#).



Related pages:

[Graphic object manipulation functions](#)
[Function arguments - types](#)