

HI_SetForeColor

%HI_GetForeColor, %HI_SetForeColor functions

Function

The function **%HI_SetForeColor** sets the fore part color of the graphic object ([Control function](#)).

The function **%HI_GetForeColor** detects the fore part color of the graphic object.

Declaration

```
%HI_SetForeColor(  
    INT in refId,  
    INT in color  
)  
  
INT %HI_GetForeColor(  
    INT in refId  
)
```

Parameters

refId	Reference to graphic object (reference variable).
color	RGB index of color.

Note

The functions use a color, that is expressed by RGB index. RGB index is a integer number, that express the color representation of the color components - red (R), green (G) and blue (B) in the result color.

The function [%MakeRGB](#) allows to form the color from individual color components.



Related pages:

- [Graphic object manipulation functions](#)
- [Function arguments - types](#)